# **ATM75**

# **(A)** audio-technica

Cardioid Condenser Headworn Microphone

artist series live sound microphones



#### **Features**

- Ideal for drummers, keyboard players, guitarists or anyone requiring hands-free operation
- · Low-visibilty headband provides stable, comfortable fit
- · Pivot-mounted flexible mic boom descends from left or right side
- Belt-mounted power module operates on battery or phantom power
- Cardioid polar pattern reduces pickup of sounds from the sides and rear, improving isolation of desired sound source
- · Rugged design and construction for reliable performance
- Switchable 80 Hz high-pass filter minimizes pickup of undesired low-frequency sounds
- Also available in two additional versions (without power module) ATM75cW – cable terminated for A-T UniPak® wireless systems ATM75c – unterminated cable

#### ATM75 Description

The ATM75 is a headworn condenser microphone with a cardioid polar pattern. It is designed for use by performing musicians and others who require professional-quality vocal pickup with hands-free operation.

The microphone requires 11V to 52V phantom power or a 1.5V AA battery for operation. A battery need not be in place for phantom power operation.

The microphone's cardioid polar pattern provides a 120° angle of acceptance.

The microphone includes a 1.4 m (4.6') permanently attached miniature cable. Its free end connects to the provided AT8531 power module via a TA3F-type connector. The output of the power module is a 3-pin XLRM-type connector.

A 3-position switch in the power module permits choice of off, on/flat response or on/low-roll-off (via integral 80 Hz high-pass filter). The roll-off position reduces the pickup of low-frequency ambient noise.

The microphone comes equipped with a power module, a cable clip, a large windscreen, a small windscreen and a battery.

## ATM75cW Description

The microphone is also available in a wireless model, the ATM75cW. The ATM75cW includes a 1.4 m (55") permanently attached miniature cable terminated with a locking 4-pin connector for use with Audio-Technica UniPak® body-pack transmitters. No power module or battery is included (or required) with the ATM75cW. The ATM75cW dimensions, polar pattern, and included accessories are otherwise identical to those of the ATM75.

The ATM75cW is also available with a 2.2 m (7.2') unterminated cable as the ATM75c.

#### **Operation and Maintenance**

The ATM75 requires 11V to 52V phantom power or a 1.5V AA battery for operation. A battery need not be in place for phantom power operation.

To install the battery, remove the cap from the top of the power module. Insert a fresh 1.5V AA battery ("+" end toward the cap release button), then reassemble the power module. For longest battery life, the switch should remain off except when the microphone is in use. Alkaline batteries are recommended for longest life. Remove the battery during long-term storage.

Output is low impedance (Lo-Z) balanced. The signal appears across Pins 2 and 3; Pin 1 is ground (shield). Output phase is "Pin 2 hot"—positive acoustic pressure produces positive voltage at Pin 2.

A 3-position switch in the power module permits choice of off, on/flat response, or on/low-roll-off (via integral 80 Hz high-pass filter). The roll-off position reduces the pickup of low-frequency ambient noise (such as traffic, air-handling systems, etc.), room reverberation and mechanically coupled vibrations. To engage the high-pass filter, slide the switch toward the "bent" line. To turn the microphone on without engaging the high-pass filter, slide the switch toward the flat line.

For maximum stability and minimum visibility, the headband should be worn around the back of the head, with each cushioned support pad resting on the temple in front of the ear. The cable should remain clipped to the headband, with some slack at the boom connection. The headset is designed so the microphone descends from the left or right side.

After use in high-moisture applications, such as aerobics instruction, on-stage performing, etc., remove the foam screen, wipe off the headset with a towel and permit them to air-dry. (Do not store in a closed space, such as a plastic bag, until all moisture has evaporated.)

Avoid leaving the microphone in the open sun or in areas where temperatures exceed 110° F (43° C) for extended periods. Extremely high humidity should also be avoided.

To reduce the environmental impact of a multi-language printed document, product information is available online at www.audio-technica.com in a selection of languages

Afin de réduire l'impact sur l'environnement de l'impression de plusieurs langues, les informations concernant les produits sont disponibles sur le site www.audio-technica.com dans une large sélection de langue.

Para reducir el impacto al medioambiente, y reducir la producción de documentos en varios leguajes, información de nuestros productos están disponibles en nuestra página del Internet: www.audio-technica.com

Para reduzir o impacto ecológico de um documento impresso de várias linguas, a Audio-Technica providência as informações dos seus produtos em diversas linguas na www.audio-technica.com.

Per evitare l'impatto ambientale che la stampa di questo documento determinerebbe, le informazioni sui prodotti sono disponibili online in diverse lingue sul sito www.audio-technica.com.

Der Umwelt zuliebe finden Sie die Produktinformationen in deutscher Sprache und weiteren Sprachen auf unserer Homepage: www.audio-technica.com

Om de gevolgen van een gedrukte meertalige handleiding op het milieu te verkleinen, is productinformatie in verschillende talen "on-line" beschikbaar op: www.audio-technica.com.

本公司基於減少對環境的影響,將不作多語言文件的印刷,有關產品訊息可在 www.audio-technica.com的官方網頁上選擇所屬語言及瀏覽

本公司基于减少对环境的影响,将不作多语言文檔的印刷,有关产品信息可在 www.audio-technica.com的官方网页上选择所属语言和浏览。

자원절약, 환경보호를 위해 국문 사용 설명서는 인쇄하지 않았습니다. 제품정보는 www.audio-technica.com 에서 원하는 언어 선택 후에 다운로드 받으실 수 있습니다.

### **Specifications**

Element	Fixed-charge back plate, permanently
	polarized condenser
Polar pattern	Cardioid

Polar pattern Frequency response Low frequency roll-off Open circuit sensitivity

100-13,000 Hz 80 Hz, 18 dB/octave

Phantom: -51 dB (2.8 mV) re 1V at 1 Pa Battery: -53 dB (2.2 mV) re 1V at 1 Pa

Impedance Phantom: 200 ohms Battery: 270 ohms

Maximum input sound level

Phantom: 132 dB SPL, 1 kHz at 1% T.H.D. Battery: 121 dB SPL, 1 kHz at 1% T.H.D.

Dynamic range (typical) Phantom: 96 dB, 1 kHz at Max SPL

Battery: 85 dB, 1 kHz at Max SPL Signal-to-noise ratio1 58 dB, 1 kHz at 1 Pa Phantom power requirements 11-52V DC, 2 mA typical

Battery type Battery current / life

1.5V AA/UM3 0.4 mA / 2000 hours typical (alkaline)

Switch Weight

Off, on-flat, on-roll-off Microphone: 60 g (2.1 oz)

Power module: 139 g (4.9 oz) Dimensions

Microphone: 20.4 mm (0.80") diameter Power module: 84.0 mm (3.31") H x 63.0 mm (2.48") W x 22.0 mm (0.87") D Headset: 120.0 mm (4.72") nominal at widest point, 80.5 mm (3.17") flexible

Output connector Power module: Integral 3-pin XLRM-type

1.4 m (4.6') long (permanently attached to microphone), 2.8 mm (0.11") diameter,

2-conductor shielded cable with TA3F-

type connector

Audio-Technica case style Accessories furnished

M19


AT8531 power module; AT8439 cable clip; AT8139L large windscreen; AT8139S small windscreen; battery

In the interest of standards development, A.T.U.S. offers full details on its test methods to other industry professionals on request.

1 Pascal = 10 dynes/cm<sup>2</sup> = 10 microbars = 94 dB SPL

1 Typical, A-weighted, using Audio Precision System One Specifications are subject to change without notice.

frequency response: 100-13,000 Hz



polar pattern

